



Series 211200TEPDSS4

MEGAFLANGE®
Restrained Flange Adapter

CONTAINS ALL DOMESTIC HARDWARE

Installation Instructions

1. Identify the pipe. The MEGAFLANGE 2100 Flange Adapter, sizes 3 inch through 12 inch, is designed for use on ductile iron pipe, PVC (C900 & IPS O.D. (ASTM D2241)) pipe, HDPE pipe, and carbon steel pipe. Check to see if the spacers under the screws are in place. If the pipe is ductile iron or C.I. O.D. PVC (C900) DO NOT REMOVE THE SPACERS. If the pipe is carbon steel or IPS O.D. PVC, REMOVE THE SPACERS (sizes 4-inch through 12-inch). The 3-inch size is designed for use on ductile iron, IPS O.D. PVC pipe. Sizes 30-inch and larger are designed for ductile iron pipe only. There are no spacers on the 3 inch and the 14 inch and larger sizes.
2. Cut the pipe to the required length. Clean the end of the pipe for a length approximately one foot using a wire brush if needed, removing all excess paint and foreign material. Also clean the opposing flange to be connected to the 2100. Place the 2100 restraint ring on the clean pipe with the lip facing the plain end.
3. Lubricate and place the EBAA-Seal™ Gasket on the clean pipe following the restraint ring. (USE A TRANSITION GASKET IN PLACE OF THE EBAA-SEAL GASKET FOR CARBON STEEL AND IPS. O.D. PVC PIPE.)
4. Place the O-ring into the groove of the 2100 Gasket Ring. (This step may have been completed at the factory, check Gasket Ring to see if O-ring is already in place.) Place the Gasket Ring on the pipe with the O-ring facing the pipe end and the gasket recess facing the EBAA-Seal (or transition) Gasket and restraint ring.
5. Bring the pipe and flanges together within the maximum assembled deflection and maximum allowable gap "L" to the flange face. Slide the gasket ring, gasket and restraint ring until contact is made with the opposing flange.
6. Insert and tighten all flange bolts. Torque all flange bolts an alternating manner to the value listed in Table 1.1. Be sure to make any necessary joint deflection before tightening the actuating screws. Joint deflection should not exceed the maximum allowable deflection. Be sure that deflection of the joint does not cause the end of the pipe to be separated from the opposing flange more than the maximum allowable gap "L".
7. Tighten the actuating screws in an alternating manner until all wedges touch the pipe. Continue tightening the nuts in an alternating pattern until all the torque-limiting nuts have been twisted off.
8. If removal is necessary, utilize the 5/8 inch hex head provided. For reinstallation, repeat steps 2 through 7, torquing the actuating screws to 70 ft.-lbs (120 ft.-lbs for 2124 through 2148). or until the hex heads bottom out on the spacers or gland.



CONTENTS

Qty.	Description
1	12 in. 2100 Restraint and Gasket Ring
1	12 in. EPDM Transition Gasket
1	12 in. O-ring Gasket
12	7/8 in. x 7 1/2 in. Stainless Steel Bolts w/ Nuts
1	Gasket Lubricant Packet

Restraints Made in The USA



APPROVED
For use on water or wastewater pipelines subject to hydrostatic pressure and tested in accordance with either AWWA C600 or ASTM D2774

APPROXIMATE SHIPPING WEIGHT: 74.33 lbs.

Copyright 2026 © EBAA IRON, Inc. All Rights Reserved

Series 211200TEPDSS4

MEGAFLANGE®
Restrained Flange Adapter



2 1 1 2 0 0 T E P D S S 4

EBAA IRON SALES, Inc.

P.O. Box 857, Eastland, TX 76448

Tel: (254) 629-1731

Fax: (254) 629-8931

Toll: (800) 433-1716

contact@ebaa.com

www.ebaa.com

Made in the USA